

OPTIONS that can be entered into the Vessel Name Field of RPT01.  
Multiple options can be entered seperated by SPACES only.  
Only the first letter(s) need be entered if desired.  
i.e. GRAIN SOL NPASS or G S N or GR S NP

---

SOL - Only use the first SOL datetime to determine which lockages fall within the given date range when calculating in-use hours. Entire lockages (all cuts) are used, even if they fall outside of the date range. This is the same as the original rpt01.

The default is to only include those cuts that fall within the date range. If part of a cut falls outside the date range, only that portion of the cut within the date range is used.

USHOW - Show the percent Lock Utilization on a Combined Chamber report. The default is to NOT show the percent lock utilization on a combined chamber report, the same as the original rpt01.

GRAIN - Commodity codes used for grain are 60,62,63,64,65,66, the same as the original rpt01.  
The default is to use commodity codes 62,63,64,65 for grain.

NPASS - Show total Navigable Pass hours on the report. Subtract out navigable pass hours from percent utilization.  
The default is to not show navigable pass hours.

CHMBR - Increase the Available Hours by multiplying the reporting period by the number of chambers. ONLY used in a Combined Chamber report, otherwise ignored. Gives equal weight to each chamber for locking boats.

BSKIP - Don't display a blank report when there is no data. The default is to output a report even though there is no data to display.

\_file - Where file is a filename (uppercase) of an existing file of river,lock,chamber,direction, one per line.  
The filename is preceded with an underscore character.  
Allows a single report to include more than one river.  
These files would be pre-built on the server.  
i.e. file ALL\_LOCKS would be entered as \_ALL\_LOCKS

LIST - List of available files that can be used with the \_file option shown above. All other options are ignored except HELP and EXPLAIN which take precedence.

HELP - Output this RPT01 Help Screen as a report.  
All other options are ignored.

EXPLAIN - Output a report explaining some of the calculated values.  
All other options are ignored except HELP which takes precedence.